
Cross-Border NL (GTS Rules) Jemgum





Administration of THE and TTF Inventory



* Extract	from	the	month	ıly	report
-----------	------	-----	-------	-----	--------

		Inver	ntory	Allocation		in-storage trades & loans		Cross Border Flow	
	Hour	TTF	THE	TTF allocation	THE allocation				
Gasday	(UTC)	inventory	inventory	from TTF	from THE				
	(3.5)	ve.iico.,		inventory	inventory	TTF	THE	TTF < THE	TTF> THE
01.11.2024	06:00:00	A 2.100	1.200	200	100	0	0	0	0
01.11.2024	07:00:00	2.300	1.300	200	100	0	0	0	0
01.11.2024	08:00:00	2.500	B 1.400	200	100	0	0	0	0
01.11.2024	09:00:00	2.700	1.500	200	100	0	0	0	0
01.11.2024	10:00:00	2.900	1.600	200	100	0	0	0	0
01.11.2024	11:00:00	3.100	1.700	200	100	0	0	0	0
01.11.2024	12:00:00	C 3.300	1.800	-400	-100	0	0	0	0
01.11.2024	13:00:00	2.900	1.700	-400	-100	0	0	0	0
01.11.2024	14:00:00	2.500	D 1.600	-400	-100	0	0	0	0
01.11.2024	15:00:00	2.100	1.500	-400	-100	0	0	0	0
01.11.2024	16:00:00	E 1.700	1.400	Ū	-100	-310	0	0	0
01.11.2024	17:00:00	1.390	1.300	-400	-100		0	0	0
01.11.2024	18:00:00	990	1.200	-400	-100	0	0	0	0
01.11.2024	19:00:00	590	1.100	-400	-100	0	0	0	0
01.11.2024	20:00:00	F 190	1.000	-600	-100	0	0	410	0
01.11.2024	21:00:00	G O	490	0	-100	0	0	0	0

- Injection of TTF increases the "TTF Inventory" (see chart A)
- Injection of THE increases the "THE Inventory" (see chart B)
- Withdrawl to TTF reduces the "TTF Inventory" (see chart C)
- Withdrawl to **THE** reduces the "**THE** Inventory" (see chart **D**)
- Gas-in-Store Transfer from the TTF Inventory account (see chart E)
- Cross-Border Flow (see chart F)
- THE Inventory and TTF Inventory cannot be negative (see chart G)

Determining the hourly Cross-Border Flow



Cross-Border Flow TTF → THE

- All working gas quantities withdrawn from the Jemgum Storage Facility and fed into a **THE** balancing group are taken from the **THE Inventory** until it reaches zero (0). In the case of further withdrawls into a **THE** balancing group, the working gas quantities are taken from the **TTF Inventory** account, which represents a Cross-Border Flow from **TTF** to **THE**.

Cross-Border Flow THE → TTF

- All working gas quantities withdrawn from the Jemgum Storage Facility and fed into a TTF balancing group are taken from the TTF Inventory until it reaches zero (0). In the case of further withdrawls into a TTF balancing group, the working gas quantities are taken from the THE Inventory account, which represents a Cross-Border Flow from THE to TTF.

Determination and invoicing of Cross-Border Capacity by GTS



Determination of Cross-Border Capacity

 Cross-Border Capacity is the maximum hourly Cross-Border Flow in kWh/h on the respective gas day.

Invoicing of Cross-Border Capacity

- The determined Cross-Border Capacity is settled at 75% of the transport tariff applicable on the respective day.
 - Cross-Border Flow **TTF** → **THE**: Firm capacity Exit Storage Day *
 - Cross-Border Flow **THE** → **TTF**: Firm capacity Entry Storage Day *

Date of invoicing:

The invoice is issued in the following month for the previous month.

^{*} see GTS TSC, Appendix 1 Network points and prices, worksheet "All other points"

Nomination procedure Cross-Border NL



Cross-Border GER (REGENT Rules)



Cross-Border NL (GTS Rules)

Storage accounts	kWh		balancing-group
THE Inventory	280 i		
TTF Inventory	150 i	240	1115

nomination procedure

nomination

 \rightarrow

Nomination example:

If a nomination of 240 kWh is made to the TTF market area, our system will confirm this with 150 kWh at time X of the gas day, since from the "REGENT" point of view, only 150 kWh are available in **ND TTF** account. If the difference of 90 kWh is transfered from **ND THE** account to **ND TTF** account in our customer portal, in consideration of the lead time, the nomination of 240 kWh is then confirmed.